

Road Tanker Sampling Valve

Safety Sampling Valve


The Road Tanker Sampling Valve is designed to allow road tankers to be safely sampled before the tank is discharged.

The Road Tanker valve is able to quickly connect to tanks that have been fitted with either a 2½" or a 3" BSP outlet.

The Road Tanker Sampling Valve is designed to allow road tankers to be safely sampled before the tank is discharged.




Operation



1. Connect the Road Tanker Sampling Valve to the main discharge valve on the road tanker.

2. Ensure that the Sampling Valve is in the closed position, then open the main discharge valve



3. Close the main discharge valve

4. Open the sampling valve and collect the sample

Part No.	Tanker Connection	Outlet Valve Type	Material	Main Gasket Material
675 5740P1	2½" BSP	Standard	316L ss	PTFE
675 5740P2	2½" BSP	Firesafe	316L ss	PTFE
675 5740P3	3" BSP	Standard	316L ss	PTFE
675 5740P4	3" BSP	Firesafe	316L ss	PTFE

[QUICK QUOTE LINK](#)

[ONLINE PRICING LINK](#)